



PORSCHE

# Maintenance intervals for Porsche vehicles

07/2010

Model	Model Year (MY)	Minor maintenance Intermediate maintenance*	Major maintenance Maintenance*	Annual maintenance**	Engine oil & Oil filter	Spark plugs	Air filter	Brake fluid
Boxster/Boxster S Cayman/Cayman S (from 2006)	2001–2004	every 20,000 km or every 2 years	every 40,000 km or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 20,000 km or every 2 years	every 80,000 km or every 4 years	every 40,000 km or every 4 years	every 2 years
	2005–2008	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
	2009	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
	2010	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 4 years	every 90,000 km or every 6 years	every 2 years
Carrera Carrera S	2001–2004	every 20,000 km or every 2 years	every 40,000 km or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 20,000 km or every 2 years	every 80,000 km or every 4 years	every 40,000 km or every 4 years	every 2 years
	2005–2008	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
	2009–2010	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 4 years	every 90,000 km or every 6 years	every 2 years
911 Turbo	2001–2004	every 20,000 km or every 2 years	every 40,000 km or every 4 years	annual mileage of less than 15,000 km per year (only until MY 03)	every 20,000 km or every 2 years	every 40,000 km	every 40,000 km or every 4 years	every 2 years
	2005–2008	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 60,000 km or every 4 years	every 60,000 km or every 4 years	alle 2 Jahre
	2009	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 60,000 km or every 4 years	every 60,000 km or every 4 years	every 2 years
	2010	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 60,000 km or every 4 years	every 90,000 km or every 6 years	every 2 years
Cayenne	2003–2009	every 30,000 km or every 2 years	every 60,000 km or every 4 years		flexible, max. 30,000 km or every 2 years	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
	2010	every 30,000 km or every 2 years	every 60,000 km or every 4 years		flexible, max. 30,000 km or every 2 years	every 90,000 km or every 6 years	every 120,000 km or every 6 years	every 2 years
	2011	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 6 years	every 120,000 km or every 6 years	every 2 years
Cayenne Diesel	2009	every 30,000 km or every 2 years	every 60,000 km or every 4 years		flexible, max. 30,000 km or every 2 years		every 120,000 km or every 4 years	every 2 years
	2010	every 30,000 km or every 2 years	every 60,000 km or every 4 years		flexible, max. 30,000 km or every 2 years		every 90,000 km or every 6 years	every 2 years
	2011	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years		every 90,000 km or every 6 years	every 2 years
Cayenne S Cayenne GTS	2003–2009	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
	2010	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 6 years	every 120,000 km or every 6 years	every 2 years
	2011	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 6 years	every 120,000 km or every 6 years	every 2 years
Cayenne S Hybrid	2011	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 6 years	every 120,000 km or every 6 years	every 2 years

\* The 'Minor maintenance' and 'Major maintenance' were renamed as 'Intermediate maintenance' and 'Maintenance' in 2009.

\*\* On vehicles with an annual mileage of less than 15,000 km (9,000 mls), annual maintenance must be carried out once a year.



PORSCHE

# Maintenance intervals for Porsche vehicles

07/2010

Model	Model Year (MY)	Minor maintenance Intermediate maintenance*	Major maintenance Maintenance*	Annual maintenance**	Engine oil & Oil filter	Spark plugs	Air filter	Brake fluid
Cayenne Turbo Cayenne Turbo S	2003-2009	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 60,000 km or every 4 years	every 120,000 km or every 4 years	every 2 years
	2010	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 60,000 km or every 6 years	every 120,000 km or every 6 years	every 2 years
	2011	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 60,000 km or every 6 years	every 120,000 km or every 6 years	every 2 years
Panamera S Panamera 4S	2010	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 90,000 km or every 6 years	every 120,000 km or every 6 years	every 2 years
Panamera Turbo	2010	every 30,000 km or every 2 years	every 60,000 km or every 4 years		every 30,000 km or every 2 years	every 60,000 km or every 6 years	every 120,000 km or every 6 years	every 2 years

\* The 'Minor maintenance' and 'Major maintenance' were renamed as 'Intermediate maintenance' and 'Maintenance' in 2009.

\*\* On vehicles with an annual mileage of less than 15,000 km (9,000 mls), annual maintenance must be carried out once a year.